


# Do not disturb & make up room system introduction



① When indoor switch of "DND" & "MUR" are off, outdoor indicator of "DND" & "MUR" show no light. With this working condition, push the doorbell switch of outdoor indicator, buzzer indoor will make a sound "Ding Dong".

② When indoor switch of "MUR" is on, outdoor indicator of "MUR" shows blue light. With this working condition, push the doorbell switch of outdoor indicator, buzzer indoor will make a sound "Ding Dong".

③ When indoor switch of "MUR" is on, "MUR" indicator shows blue light. But at the same time, you push "DND" switch on, outdoor indicator of "DND" show red light, but "MUR" indicator **can't** work. With this working condition, push the doorbell switch of outdoor indicator, buzzer indoor **can't** make a sound "Ding Dong". Hence, if you want to use "MUR" function, please keep "DND" switch off.

